

CE Installation instructions




**AKO-D14120 AKO-D14123 AKO-D14012
AKO-D14023 AKO-D14023-C AKO-D14024
AKO-D14124 AKO-D14125**

1- Warnings


- Using the equipment without following the manufacturer's instructions may affect the device's safety requirements. To ensure that the device operates correctly, only probes supplied by AKO should be used.
- The unit must be installed in a location protected from vibrations, water and corrosive gases, where the ambient temperature does not exceed that shown in the technical data.
- To ensure a correct reading, the probe must be situated in a location without any external heat influences except for the temperature which is being measured or controlled.
- The power supply circuit must be provided with a main switch rated at at least 2 A, 230 V, located close to the equipment. The cables will enter through the back and should be type H05VV-F or H05V-K.
- The gauge will depend on local regulations, but should in no case be less than 1 mm².
- Connecting wires for the relay contacts should be sized 2.5 mm².
- Between -40 °C and +20 °C, if the probe NTC is prolonged till 1.000 m with a minimum of cable 0.5 mm², the maximum deviation will be of 0.25 °C (extension cable for probe ref. AKO-15586)
- NOTE:** Equipment not compatible with AKO-14917 (external communication module) and AKO-14918 (programming key).

2- Installation




3- Wiring

The probe and its cable should **NEVER** be installed in the same conduit as power, control or supply cables.



4- Operation

3 key equipment



SET key

Press for 5 seconds to modify the set point (SP).

Press for 10 seconds to go to the programming menu.

In the programming menu, go to the level displayed or accept the new value while setting a parameter.

Up key ▲ / ⚡

Pressing for 5 seconds starts/stops defrosting.


In programming menu, allows you to scroll through the various levels or, during the setting of a parameter, to change the value.

Down key ▼ / ⌂

Pressing for 5 seconds activates Standby mode, pressing for 2 seconds returns the equipment to normal mode. In Standby mode, the equipment performs no actions and only the ⌂ indicator is displayed on the screen.

In programming menu, allows you to scroll through the various levels or, during the setting of a parameter, to change the value.

1 key equipment



SET key / ⌂

Pressing for 5 seconds activates Standby mode, pressing for 2 seconds returns the equipment to normal mode. In Standby mode, the equipment performs no actions and only the ⌂ indicator is displayed on the screen.

Pressing for 10 seconds goes to the programming menu.

Pressing for 5 seconds in the programming menu goes to the level displayed on the screen or, during the setting of a parameter, accepts the new value.

In the programming menu, a short press allows you to scroll through the various levels or, during the setting of a parameter, to increment the value. When upper limit is reached, it will start again from the lower limit.

5- Start-up

(Only 3 key models)


On power-up, the equipment will start up in Wizard mode (P3 / 1 flashing), press ▲ or ▼ to select the most appropriate application and press SET.

- | | | |
|-----------------|----------------------|--------------------------|
| 1: Multipurpose | 2: Frozen | 3: Fruits and vegetables |
| 4: Fresh fish | 5: Soft Drinks | 6: Bottle racks |
| 7: AC | 8: Heat / Incubators | |

The wizard will configure the parameters of the equipment for the chosen application (see table "Default settings by application").

5.1- Access to set point and programming

3 key equipment



1 key equipment



Information on our web site: www.akoelectromecanica.com
different from those described in our Data Sheets. Updated
We reserve the right to supply materials which may be slightly

AKO ELECTROMECANICA, S.A.L.
Tel. (34) 938 142 700
Fax (34) 938 934 054
www.akoelectromecanica.com

35D141232 REV03 2013

Barceló (Espana)

Av. Ronda de Madrid, 30-38

Balneario de Ribes

08122 Sant Feliu de Guíxols (España)

User Manual available at <http://www.akoelectromecanica.com/4dpulsepage/qrcode=AKOD0C0017>

AKO

www.akoelectromecanica.com




5.2- Setting parameters


Programming Menu (parameters)

After 20 seconds with no key being pressed, the equipment will return to the previous level. If you are on level 3, the changes will not be saved


3 KEY EQUIPMENT



1 KEY EQUIPMENT



Change set point (only equipment with three keys)



6- Table of parameters and messages

Def. column shows factory-set default parameters. Those marked with * are variable parameters depending on the application chosen in the wizard or the P3 parameter (see table "Default parameters by application"). Unless otherwise stated, temperatures are expressed in °C. (Equivalent values in °F)

AKO-D14023-C AKO-D14012, AKO-D14023, AKO-D14024 AKO-D14120, AKO-D14123, AKO-D14124, AKO-D14125							
Level1 Menus and description							
rE	Level 2 Control	Level 3 Description	Values	Min.	Def.	Max.	
SP		Temperature Adjustment (Set Point) (limits depending on probe type)	With NTC (°C/°F) With PTC (-50 (-58°F))	* -50 -150 (302°F)	99 150 (210°F)	•	
		C0 Calibrating probe 1 (Offset) (°C/°F)	-20.0	0.0	20.0	•	•
C1		Probe 1 differential (Hysteresis) (°C/°F)	0.1	2.0	20.0	•	
C2		Upper blocking of the set point (cannot be set above this value)	With NTC (210°F) With PTC (210°F)	99 -150 (302°F)	99 150 (210°F)	•	
		C3 Lower blocking of the set point (cannot be set below this value) (°C/°F)	-50 (-58°F)	-50 (-58°F)	C2	•	
C4		Type of delay for protection of the compressor: 0=OFF/ON (since the last disconnection); 1=ON (since start-up/reset); 2=OFF-ON/ON-OFF (since the last shut-down/start-up)	0	0	2	•	
C5		Protection delay time (value of the option selected in parameter C4) (min.)	0	0	120	•	
C6		Status of COOL relay with probe fault 0=OFF; 1=ON; 2=Average based on last 24 hours prior to probe fault; 3=ON-OFF as prog. C7 and C8	0	0	3	•	
C7		Time relay ON in case of faulty probe (If C7=0 and C8=0, the relay will always be OFF deenergised) (min.)	0	10	120	•	
C8		Time relay OFF in case of fault of probe 1 (If C8=0 and C7=0, the relay will always be ON energised) (min.)	0	5	120	•	
EP		Exit to Level 1				•	•
dEF Level 2 DEFROST Control (if P0=0 Direct, Cold)							
d0	d1	d2	d3	d8	EP	Exit to Level 1	
Defrost frequency (Time between two starts)	Maximum defrost duration (0=defrost deactivated)	Type of message during defrost: 0=Current temperature; 1=Temperature at start of defrost; 2=Display DEF message	Maximum duration of message (time added at the end of the defrost)	Calculated time between defrost periods: 0=Total actual time; 1=Sum of times the compressor is on			
(h.)	(min.)	0	0	0	0	0	
0	0	*	2	255	*	•	
96	255	2	2	2	1	•	
CnF Level 2 General status							
P0	P1	P2	P5	P7	P9	EP	Exit Programming
Type of operation 0=Direct, Cold;1=Inverted, Heat	Delay of all functions on receiving electrical power (min.)	0=Inactive; 1=Block access to parameters; 2=Keyboard lock	Address (only systems with built-in communications)	Temperature display mode 0=Integer °C 1=One decimal in °C 2=Integer °F 3=One decimal in °F	Selection of probe type 0=NTC; 1=PTC	Exit to Level 1	Exit Programming
0	0	0	1	0	0	0	0
*	0	2	255	1	3	1	1
1	255	•	•	•	•	•	•
tid Level 2 Access and information control							
L5	PU	Pr	EP	EP	EP	EP	EP
Access code (Password)	Program version (Information)	Program revision (Information)	Exit to Level 1	Exit Programming			
0	-	-	0	0	0	0	0
-	-	-	1	1	1	1	1
99	•	•	99	99	99	99	99



WARNING: The default parameters by type of application have been defined for the most common applications. Check that these parameters are suitable for your installation.

DEFAULT SETTINGS BY APPLICATION (P3)							
1 Multipurpose	2 Frozen	3 Fruit and Vegetables	4 Fresh Fish	5 Soft Drinks	6 Bottle Racks	7 AC	8 Heat/ Incubators
2 (35,6°F)	-18 (-0,4°F)	10 (50°F)	0 (32°F)	3 (37,4°F)	12 (53,6°F)	21 (69,8°F)	37 (98,6°F)
d0 4	d1 20	d2 20	d3 20	d4 24	d5 20	d6 0	d7 -
d0 4	d1 20	d2 20	d3 20	d4 24	d5 20	d6 0	d7 -
d0 0	d1 0	d2 0	d3 0	d4 0	d5 0	d6 0	d7 1
MESSAGES							
L5 Access code (Password) request	dEF Indicates a defrost is underway. (Only if parameter d2=2)	E1 Probe 1 fault (open circuit, crossover, NTC: temp. >110°C or <-55 °C PTC: temp. >150 °C or <58 °C) - (equivalent limits in °F)	D	D	-	D	S

D: Displays the message on the display

S: Shows the message in the AKONet software (Only AKO-D14023-C)

7- Technical specifications

Power supply	AKO-D14023/D14024/D14123/D14124/D14125	230V~ ±10 % 50/60 Hz 3.5VA
AKO-D14120	120V~ +8 % -12 % 50/60 Hz 4VA
AKO-D14023-C	90-240V ~ 50/60 Hz 6VA
AKO-D14012	12/24V ~ ±20 % 2.5VA
Maximum Voltage SELV circuits	20V
Communication (Only AKO-D14023-C)	Modbus RTU RS485
Inputs (According to P4)	1 NTC/PTC
Relay COOL 16 A	(EN60730-1: 120)A 250V~/
Number of relay operations	EN60730-1: 100.000 operations
Types of probe	NTC AKO-149xx / PTC AKO-155xx
Measurement range NTC	-50,0 °C to +99,9 °C (-58,0 °F to 211 °F)
PTC	-50,0 °C to +150 °C (-58,0 °F to 302 °F)
Resolution	0,1 °C
Working environment	-10 to 50 °C, humidity <90 %
Ambient storage humidity	-30 to 70 °C, humidity <90 %
Class of protection - front panel	IP65
Fixation	Panel-mounted with anchors
Panel cutout dimensions	71 x 29 mm
Front panel dimensions	79 x 38 mm
Depth	AKO-D14023-C	61 mm
Other models	43 mm
Connections	Screw terminals for cables up to 2.5 mm ²
Rating of control device: built-in, automatic operation feature Type 1.B, for use in clean environments, Class A software and continuous operation. Pollution classification 2 s/ UNE-EN 60730-1.	
Double insulation between supply, secondary circuit and relay output.	
Rated pulse voltage	2500V
Temperature during ball-pressure test	75 °C
Parts which position active elements	125 °C
AKO-D14023/D14023-C/D14024	
AKO-D14123/D14124/D14125	207 V, 17 mA
AKO-D14120	105 V, 36 mA
AKO-D14012	9,6 V, 181 mA
Current of radio jamming suppression tests	270 mA