

HC45 VENTILATION


**POLA**


## TABLE OF CONTENTS

Programming's introduction	pag. 3
Heat setting	pag. 4
Ventilation setting	pag. 5
Cool setting	pag. 7
Alarm setting	pag. 8
Inst setting	pag. 9
Special messages	pag. 9
State indication lamps	pag.10
Hand mode	pag.10
Installation	pag. 11
Wire diagram	pag. 12
Alarm connection	pag. 13
Technical data	pag. 14
Preset programs	pag. 16

## INTRODUCTION TO USER PROGRAMMING





The symbol placed at top of every paragraph indicates:



 : Settings to be performed only at plant start-up they determine working mode suited for the kind of plant existent (heating, equipments, flap tipology, etc.).




 : User common settings normally used during operation procedures (temperature, settings, speed, etc.).

 : View only operations (temperature, speed, etc.) without changing settings.

The setting mode is the same for the various programs you want to run:

Select function desired pushing appropriate ideogram key    

after push  for start-up settings or  for common settings.

At this point the message related to the parameter to be set will appear on display in alternance with the parameter value: use  to increase, or  to decrease the value to be set, when required value has been reached, push  for entering data.

In the case of sequential settings at this point the next parameter message will appear; act as already explained.

At the last settings the system will return in normal operating mode.

To escape from operation setting push the specific flashing key.


## HEAT SETTING






Press **HEAT** and then **ENTER**:  
this message will be displayed instead of the  
 $^{\circ}\text{C}$  Heat temperature value.  
Press **+** or **-** to modify, press **ENTER** to exit.

H.HEA

## HEAT PARAMETERS PROGRAMMING



Press **HEAT** together with **SERVICE**:  
this message will be displayed.

Press  to go forward, press  or  to modify.

S.E.r.v.


d.HEA  $^{\circ}\text{C}$  heating differential.

At this point pressing **ENTER** you can return at the beginning of the programming list (message **S.E.r.v.** will be displayed).


You can press **SERVICE** at any time to exit and return to the run mode.

## HEATING OPERATIVE DIAGRAMS

### Heating



## VENTILATION SETTINGS



Press **VENT** and then **ENTER**:  
this message will be displayed instead of the  
 $^{\circ}\text{C}$  *Ventilation temperature value*.  
Press **+** or **-** to modify, press **ENTER** to confirm.

t.vEn

At this point this message will be displayed instead of the  
*Minimum step*.

Press **+** or **-** to modify, press **ENTER** to confirm.

SF.\_.

If the Minimum step is set to **=0** at this point this message will  
be displayed instead of the *Set shutter running time (in minutes)*.  
Press **+** or **-** to modify, press **ENTER** to confirm.

t.on.P

At this point this message will be displayed instead of the  
*Set shutter dwell time (in minutes)*.

Press **+** or **-** to modify, press **ENTER** to confirm.


t.of.P

At this point this message will be displayed instead of the  
*Set shutter step number*.

Press **+** or **-** to modify, press **ENTER** to exit.

PArT

## VENTILATION PARAMETERS PROGRAMMING



Press **VENT** together with **SERVICE**:

this message will be displayed.

Press  to go forward, press  or  to modify.

S.E.r.v.

**PrOp**  $^{\circ}\text{C}$  *Ventilation proportional band* \*1.

**SFAr** *Start ventilation action mode* \*2.

**=0**; 0 to 1 step becomes in normal mode

**=1**; 0 to 1 step becomes with a momentary 10 seconds at speed 2.

**=2**; 0 to 1 step becomes with a momentary 5 seconds at speed 3.

**rIF.F** *Speed step on delay seconds*.

At this point pressing **ENTER** you can return at the beginning of the programming list  
(message **S.E.r.v.** will be displayed).

You can press **SERVICE** at any time to exit and return to the run mode.

\*1 It is the complete ventilation proportional band (from lower value ventilation it starts at 1<sup>st</sup> step at  
temperature set on VENT key (**t.vEn**) and reaches last step at temperature **t.vEn+Prop**).

\*2 These settings permit to make an easier opening of shutters on ventilators.


# VENTILATION OPERATIVE DIAGRAMS

## Ventilation

The connection of ventilation steps can be:

- Speed regulation (each step start turns off the former step)
- Progressive order (9-10 terminals closed); each step start maintains the former step.

If Minimum speed is programmed to 0 ( $SP\_ = 0$ ), when the ventilation is off it is possible to insert a cyclical operation of minimum speed, compound with a time of ventilators turn on ( $t.on.P$ ), with a time of ventilators turn off ( $t.oF.P$ ), and with selected speed number during fan's shuttering operation ( $Part$ ).




## COOLING SETTING






Press **COOL** and then **ENTER**:  
this message will be displayed instead of the  
°C *Cooling temperature value*.  
Press **+** or **-** to modify , press **ENTER** to confirm.

F.C.O.L

## COOL PARAMETERS PROGRAMMING



Press **COOL** together with **SERVICE**:  
this message will be displayed.

Press  to go forward, press  or  to modify.

S.E.r.v.


d.C.O.L °C *Cool temperature differential*.

At this point pressing **ENTER** you can return at the beginning of the programming list (message **S.E.r.v.** will be displayed).

You can press **SERVICE** at any time to exit and return to the run mode.

## COOLING OPERATIVE DIAGRAMS

### Cooling



## ALARM SETTING



Press **ALARM** and then **ENTER**:  
 this message will be displayed instead of the  
 °C *Minimum alarm value*.  
 Press **+** or **-** to modify, press **ENTER** to confirm.

t.AL. \_

At this point this message will be displayed instead of the  
 °C *Maximum alarm value*  
 Press **+** or **-** to modify , press **ENTER** to exit.


t.AL. -

## ALARM EXCLUSION



Press **ALARM** key for more than 2 seconds to switch-off alarm:  
 to confirm exclusion **ALARM** lamp flash.  
 Press **ALARM** key to switch-on alarm.

## VIEWING TEMPERATURE RECORDING



Press **+** :  $t. \_ \_ \_$  : will be displayed followed by  
 °C *Maximum Temperature Recording*.


Press **-** :  $t. \_ \_ \_$  will be displayed followed by  
 °C *Minimum Temperature Recording*.

Values recorder are memory permanent stored: for memory clear keep pushed **+** keys  
 for more than 3 seconds:

**CLEA** message will be composed on display before clearing operation.

## ALARM OPERATIVE DIAGRAMS

### Alarm







## INST PARAMETERS SETTING



Press + , - , **SERVICE** together for at least 1 second: this message will be displayed.

**l.n.S.t.**

Press  to go forward, press  or  to modify.

**Ad.uE** °C Ventilation temperature probe correction \*1.

**tEnP** Temperature representation:  
=1 ; °C (0,1° resolution).  
=2 ; °F (0,1° resolution).

**25.0F** Example temperature representation with **tEnP = 1**  
**92.0F** Example temperature representation with **tEnP = 2**

At this point pressing **ENTER** you can return at the beginning of the programming list (message **l.n.S.t.** will be displayed).

You can press **SERVICE** at any time to exit and return to the run mode.

\*1 You can correct the readings on the various temperature sensor (+ or -).

*Attention: temperature probe is specified with a precision of 0.2°C (typically is better than 0.1°C) so to adjust them is required almost a certified thermometer with a precision of 0.05°C.*

## SPECIAL MESSAGES ON DISPLAY

In normal condition on display appears ambient temperature.  
Some special conditions can cause following messages:

**-O.C.-**

\*1 When ambient probe has an open circuit wire failure.

**-S.C.-**

\*1 When ambient probe has a short circuit wire failure.

\*1 In this case alarm output relay is on.

## STATE INDICATION LAMPS

The lights situated at the bottom of the display show the state of the various relay of actioning.

Led	State	N° Relay	Contact
HEAT	Heat On	6	21-22
VENTILATION 1 * <sup>1</sup>	Ventilation step 1 On	1	11-12
VENTILATION 2 * <sup>1</sup>	Ventilation step 2 On	2	13-14
VENTILATION 3 * <sup>1</sup>	Ventilation step 3 On	3	15-16
VENTILATION 4 * <sup>1</sup>	Ventilation step 4 On	4	17-18
VENTILATION 5 * <sup>1</sup>	Ventilation step 5 On	5	19-20
COOL	Cool On	7	23-24
ALARM * <sup>2</sup>	Minimum or Naximum Alarm on	10	29-30

\*<sup>1</sup> Flashing during winter fan shuttering operation (flashing step selected ventilation), and during delay ventilation time (*rit.F*).

\*<sup>2</sup> Flashing when alarm is disabled.

## HC45 MANUAL MODE



In some start-up condition may be useful to work in "hand" mode

Press **+** / **-** / **ALARM** keys together for at least one second:

**HAnd** message will be displayed (release now keys).

Press **+** keys until is displayed number required to be hand (see table).

Press **ENTER** key to activate the output.

Pressing again **+** to increase relay number previous relay is deactivated.

Press **ALARM** key to exit and return to the run mode.

HC45 output	State	Note
<b>1</b>	Ventilation step 1	
<b>2</b>	Ventilation step 2	
<b>3</b>	Ventilation step 3	
<b>4</b>	Ventilation step 4	
<b>5</b>	Ventilation step 5	
<b>6</b>	Heat	
<b>7</b>	Cooling	
<b>10</b>	Main alarm	

**HC45 installation.**

Place the module in a clean and dry site.

Connect electric wires such as shown in diagram.

**How to connect the power line.**

Connect power line on **L-N** terminals; protect supply with adequate fuse.

**How to connect the auxiliary contacts:**


Connect **11-22.....29-30** terminals on the terminals block (contacts up to **4AMP.AC1**) to the loads as shown in the diagram.

Protect contacts with a **4AMP.F** fuses.

**How to connect probes and control signals.**

Connect the provided sensor (**SX**) as shown in the diagram: **for remote connections use a standard 0,5-square millimetre two-pole wire for each sensor**, taking great care over the connection, by insulating and sealing carefully the joints.

In case of strong radio-interference insert a ferrite sleeve in the cable near regulator.







## IMPORTANT:

in order to avoid that **HC45** malfunction causes damage to animal's health we suggest to install an independent minimum-maximum alarm system (example our **HP13/W** model).

**Solution 1: AP01** alarm receives the signal in parallel of all alarms and it provides to control a 12V d.c. output (with alarm buffer battery 1.1 Ah) to connect siren, telephone dialer, etc. Furthermore when there is a black-out the alarm operates.



**Solution 2: AP03/13** alarm receives the signal in parallel of all alarms of **HC45** and it controls the independent alarm of every single zone (through N.3 **HP13**). It also provides the management of a 12V d.c. output (with alarm buffer battery 1.1 Ah) for the connection of any siren, dialer etc.. Also in case of power failure the alarm is activated (after one minute).





<b>Power supply</b>	
Line voltage	220-240Vac
Frequency	50/60Hz
<b>Cabinet</b>	
Material	PVC
Dimensions	144x144x77mm
Weight	KG 1
Protection degree	IP20
<b>Outputs</b>	
Maximum relay contacts load	4A AC1
Serial output	TTL 2400 baud
<b>Inputs</b>	
Probe measuring range	-50.0...+115.0°C
Instrument precision	0.2°C
Temperature probe reading precision	0.2°C
Temperature setting range	-50.0...+115.0°C
Probe connection	2 wire without screen
<b>Temperature range</b>	
Operatibility	-10...+40°C
Storage	-40...+85°C

## CE DECLARATION OF CONFORMITY

**POLA**<sup>®</sup> declares that your **HC45** model is conform to following European normatives:

**EN 50081-1 (1992) (Emission)**

**EN 50082-2 (1995) (Immunity)**

referred to directive **EE 89/336** and subsequent **92/31** about electro-magnetic compatibility (**EMC**)

and it is conform to directive **EEC 72/23** and subsequent **EEC 93/68** about low voltage safety (**LVD**).

Measure was performed by an  
ACCREDITED COMPETENT BODY.



# PRESET PROGRAMS



This processor is already programmed with the following (variable) settings. To return to these settings at any time, press **+ / -** and **ENTER** together for at least 1 second **boot** message is displayed:

On this table are shown setting values at delivery, you are advised to record all the settings made in table below such as to have an immediate reference for the Programming and run modes.

## HEAT

Parameter	Value on delivery	Value on customer
<b>t.HEA</b>	21.0°C	
SERVICE		
<b>d.HEA</b>	0.2°C	

## VENT

Parameter	Value on delivery	Value on customer
<b>t.vEn</b>	25.0°C	
<b>SP._ _</b>	=0	
<b>t.on.P</b>	0'	
<b>t.oF.P</b>	10'	
<b>PArT</b>	=1	
SERVICE		
<b>ProP</b>	4.0°C	
<b>Star</b>	=0	
<b>rit.F</b>	0"	

## COOL

Parameter	Value on delivery	Value on customer
<b>t.COL</b>	32.0°C	
SERVICE		
<b>d.COL</b>	0.2°C	

## ALARM

Parameter	Value on delivery	Value on customer
<b>t.AL._</b>	15.0°C	
<b>t.AL.-</b>	35.0°C	

## Parametri INSt

Parameter	Value on delivery	Value on customer
<b>Ad.vE</b>	0.0°C	
<b>tEnP</b>	=1	

